Shoulder bag 27 x 18 x 20 cm

General information

Water resistant shoulder bag to safely store and transport a camera. The inner compartment of the bag includes two adjustable, padded dividers and two pockets for small accessories, such as a cleaning cloth or additional memory cards. This way, the bag can be organised as preferred to enable quick access to its contents. Additionally, it features side pockets which provide space for cables, batteries and other accessories. The bag is supplied with a detachable, adjustable shoulder strap with a non-slip patch and a handle for extra convenience.

Specifications

Colour:	Black / Green
Material:	Nylon
Type of Bag:	Shoulder
Dividers:	2
External Depth:	190 mm
External Height:	230 mm
External Width:	300 mm

Package contents

1x shoulder bag
1x carrying strap

Sales information

Order code:	**KN-PB30**
Product description:	Shoulder bag 27 x 18 x 20 cm
Packaging:	Label
Brand name:	König

5 412810 225040

Information is subject to change without prior notice. Contents may differ from what is shown. Supplier can not be held responsible, nor liable for the information contained in this document. This document was generated at 20/12/2014 14:00:30